

# Jeep Towing Prep

## Prep for flat towing the Jeep

### Steps:

- 1. Bring vehicle to a stop on level ground with engine running.
- 2. Press and hold brake pedal
- 3. Shift the transmission into NEUTRAL
- 4. If the vehicle is equipped with Quadra-Lift air suspension, ensure the vehicle is set to Normal Ride Height
- 5. Place the transfer case in NEUTRAL. Using a ball point pen push and hold the recessed N button for four (4) seconds. The light will blink, indicating shift in progress. The light will stop blinking (remain on) when the shift to NEUTRAL is complete.
- 6. Shift the transmission into REVERSE and release the brake pedal for five seconds to ensure there is no vehicle movement
- 7. Press and hold the brake pedal and shift the transmission back to NEUTRAL
- 8. Firmly apply the parking brake
- 9. With the transmission and transfer in NEUTRAL press and hold the ENGINE START/STOP button until the engine turns off
- 10. Place the transmission gear selector in PARK. Release the brake pedal
- 11. Push the ENGINE START/STOP button twice (without pressing the Parke pedal) to turn the ignition to the OFF mode
- 12. Attach the vehicle to the tow vehicle using a suitable tow bar
- 13. Ensure auxiliary braking system is operational and installed
- 14. Release the parking brake