

Instructions for towing 2019 GMC Canyon

Connecting

- Position towed vehicle directly behind motorhome
- Remove towing equipment from Motorhome aft R/H storage compartment.
- Install baseplate arms into baseplate receptacles
- Connect tow bar to arms. Insure locking pins are firmly inserted
- Connect safety cables
- Install electrical umbilical chord
- Install breakaway switch cable
- Insure all connections are secure
- Stow tow bar cover.
- Check that all lights and turn signals are working on the towed vehicle.
- Start vehicle, put in reverse and slowly back up until tow arms lock.
- Shift transfer case into neutral
 - Set parking brake
 - Start vehicle or turn ignition on
 - Shift transmission into neutral
 - Shift transfer case to 2 ↑
 - Turn transfer case knob clockwise to N (Neutral) until it stops and hold it there until the N light starts flashing. This will take at least 10 seconds. Then slowly release the knob to the 4 ↓ Position. The Neutral light will stay on when the transfer case shift to neutral is complete.
 - With the engine running, verify that the transfer case is in neutral by shifting the transmission into reverse and then into drive. There should be no movement of the vehicle while shifting the transmission.
 - Turn engine off and leave the key in the ACC/Accessory position.
 - Place transmission shift lever in Park
- Turn on Aux Brake switch.
- Lock all doors.
- Push battery disconnect switch. Verify disconnect.
- Remove ignition key and insert "Tow Key", turn to ACC/Accessory position.
- Check to ensure that the steering wheel is NOT locked. Leave "Tow Key" in ignition.
- Close driver's door and lock with ignition key.

Disconnecting

- **Unlock driver's door with ignition key**
- **Turn "Tow Key" key to off and remove.**
- **Insert ignition key.**
- **Push battery switch to reconnect battery**
- **Verify reconnect**
- **Turn off Aux Brake switch**
- **Shift transfer case out of Neutral**
 - **Set Parking Brake**
 - **Press brake pedal**
 - **Turn ignition key to on, do not start engine**
 - **Shift transmission into neutral**
 - **Turn Transfer Case knob to 2↑**
 - **After Transfer Case has shifted out of neutral the Neutral light will go out.**
 - **Put transmission into Park**
 - **Turn off ignition key**
- **Disconnect safety cables, Electrical Umbilical cord and breakaway switch cables and stow them.**
- **Disconnect tow bar and stow it. Put tow bar cover on.**
- **Release parking brake**
- **Start engine and shift transmission into reverse.**
- **Park Vehicle**