

Programming the wireless transmitter to a leveling control module.

September 4, 2012

- I. With the wired display off, press the left arrow key 5 times then the right arrow key 5 times.
- II. "Wireless configuration" will be displayed.
- III. Turn on the wireless transmitter.
- IV. Press the "OK" icon.
- V. Press the "Leveler" icon.
- VI. Press any icon on the "Leveler" screen.
- VII. The display will read "successful".