


Setting Zero Point for Units Without Auto Air Dump

Taken from Lippert Documentation



1. Turn system on by pressing the "ON/OFF" button ①. The "ON/OFF" indicator light will illuminate.
2. Press the "MAN" button ② and hold for 2-3 seconds. The indicator light will then illuminate.
3. Level coach in "MANUAL" mode by using a carpenter's level on the floor. Level front to rear and then left to right.
4. Turn Touch Panel "OFF;" then turn it on again.
5. With the coach leveled, press "FRONT" button ③ 5x.
6. Press "REAR" button ④ 5x. At this time, ALL lights on the "TOUCH PANEL" will flash.
7. The "TOUCH PANEL" is now in "IDLE" mode. If the coach has come out of it's level condition, it can be reset into level condition by pressing the directional buttons to get the coach level again. If the coach is in "LEVEL CONDITION," Press the "RETRACT ALL" button ⑤ 3x.

For more detailed instructions and/or troubleshooting assistance, please contact Lippert at 574-534-0001 or go to their website www.lci1.com