



Feedback



MAINTENANCE SCHEDULE BY EQUIPMENT

Critter Cave

Equipment ▲	Activity	Frequency				Notes
			Date	Mileage	Hours	
Awning	Inspect clean and lubricate awning	every	6 months			
Coach	Sanitize Fresh Water System	every	1 year			Sanitize the fresh water system annually.
Coach	State Safety Inspection	every	1 year			State Inspection Required
Coach	Inspect Air Compressor - check for leaks and pressure	every	2 years	20,000 miles		
Coach	Air Tanks Drain and clean	every	2 years	20,000 miles		
Coach	Inspect Air Dryer	every	2 years	20,000 miles		
Coach	Winterize Water System	every	1 year			Winterize the fresh water system annually.
Engine	Check Radiator Shutter Assembly	every	2 years	125,000 miles		
Engine	Check Engine Wiring Harness	every	1 year	50,000 miles		
Engine	Viscous - Inspect Vibration Damper	every	2 years	250,000 miles		
Engine	Overhead Adjustment	every	48 months	150,000 miles		
Engine	Check Cooling Fan Belt Tensioner	every	1 year	50,000 miles		
Engine	Change Fuel Filter	every	1 year	15,000 miles		
Engine	Engine Steam Cleaning	every	2 years	125,000 miles		
Engine	Particulate Filter Cleaning	every		200,000 miles		
Engine	Adjust Engine Brake	every	2 years	250,000		

miles					
Engine	DEF Filter	every	200,000 miles		
Engine	Change Oil and Filter	every 1 year	15,000 miles		
Engine	Check Engine Mounting Bolts	every 2 years	125,000 miles		
Engine	Test Radiator Pressure Cap	every 6 months	25,000 miles		
Engine	Check Air Leaks, Air Intake and Exhaust Systems	every 1 year	50,000 miles		
Engine	Crankcase Breather Element	every 3 years	45,000 miles	This needs to be done every 3rd or 4th oil change	
Engine	Automatic - Check Belt Tensioner, Refrigerant Compressor	every 1 year	50,000 miles		
Engine	Check Radiator Hoses	every 2 years	125,000 miles		
Engine	Check Cold Starting Aid	every 2 years	125,000 miles		
Engine	Oil Testing	every 1 year		See Engine fluid testing information on Maintainmyrv.com for instructions on how to do this yourself., or have your service provider do it.	
Engine	Test Coolant	every 1 year		See Engine fluid testing information on Maintainmyrv.com for instructions on how to do this yourself., or have your service provider do it.	
Engine	Flush Cooling System	every 2 years	250,000 miles	Use coolant testing to best determine when to flush the system - see maintainmyrv.com on testing process and tools	
Engine	Check Charge on Air Cooler	every 6 months	25,000 miles		
Front AC	Access and Clean the Evaporators	every 1 year			
Front AC	Clean & or Change Air Filters	every 1 month			
Front AC	Clean and Straighten the Condenser Fins	every 1 year			
Front AC	Inspect the Upper Plastic Shroud for Cracks and Deterioration	every 1 year			
Generator	Flush Coolant System - Quiet Diesel	every 5 years	1,000 hours	Perform at least once every five years.	
Generator	Change Air Filter	every	500 hours	Perform more often when operating in dusty environments. Perform sooner if engine performance deteriorates	
Generator	Clean Spark Arrestor	every 1 year	150 hours	Perform at least once a year. Perform sooner if engine performance deteriorates	

Generator	Clean and Check Battery Connections	every	6 months		Perform more often when operating in warm hot weather
Generator	Change Fuel Filter - Quiet Diesel	every		500 hours	Perform sooner if engine performance deteriorates
Generator	Change Oil/Oil filter - QD 5500/6000/7500/8000 HQD 810/1218	every	1 year	150 hours	1. As a part of engine break-in, change the engine oil after the first 20-50 hours of operation. 2. Perform more often when operating in dusty environments. 3. Perform more often when operating in hot weather. 4. Perform at least once a year.
Rear AC	Inspect the Upper Plastic Shroud for Cracks and Deterioration	every	1 year		
Rear AC	Clean & or Change Air Filters	every	1 month		
Rear AC	Access and Clean the Evaporators	every	1 year		
Rear AC	Clean and Straighten the Condenser Fins	every	1 year		
Refrigerator	Replace Air Filter	every	1 year		
Refrigerator	Replace Water Filter	every	1 year		
Towbar	Inspect trailer wiring connects, lights	every	6 months		
Towbar	Check torque and tighten all bolts if needed (each trip)	every	6 months		
Towbar	Check condition and operation of emergency brake away cable (each trip)	every	6 months		
Trans	Change Transmission Fluid	every	48 months	150,000 miles	Local Conditions, severity of operation, or duty cycle may require more or less frequent fluid change intervals that differ from the published recommended fluid change intervals. Transmission protection and fluid change intervals can be optimized by using fluid analysis. See maintainmyrv.com for information on testing the fluids using our partners.
Trans	Obtain Fluid Sample and Analysis	every	1 year		
Trans	Change Main and Lube Filters	every	36 months	75,000 miles	** Recommendations are based on the transmission containing 100% TranSynd Fluid and Allison Transmission Gold Series Filters.